



ORDER OF INSTALLATION

1. Layout and identify all parts.
2. Insert door rollers into long portion of "H" shaped aluminum door channel approximately 1-1/2" from each end.
3. Install vinyl glazing on bottom edge of glass doors. (Vinyl glazing shipped loose.)
4. Slide aluminum door channels onto glass doors at vinyl glazing.
5. Slide rubber door guides onto top of glass doors approximately 1-1/2" from each end.
6. Slip entire door assembly upwards into top track and let rollers rest on round portion of lower track assembly.

