



310 Series Bulletin Board Cabinet



INSTALLATION INSTRUCTIONS

Installation Instructions

1. Determine desired height of the top of the cabinet and mark a line.
2. Lay the cabinet face down and engage the Z bar hangers into the hangers mounted on the back of the cabinet.
3. Measure from the top of the cabinet to the bottom of the engaged z bar hanger. Transfer that measurement to the wall down from the desired height mark and strike a level line.
4. Place the bottom of the hanger on the level line and secure with proper wall fasteners.
5. Use a straight edge to check for flatness. Hangers may need to be shimmed accordingly.
6. From the desired height mark measure down the height of the cabinet minus 1/2 "and mark a level line. Drill on the line to secure the angle clips. Clips should be plumb with the hangers. Use appropriate fasteners to mount the angle at its lowest point. Do not overtighten the clip to the wall. This will allow for the clip to be adjusted.
7. Install the cabinet by raising the cabinets slightly higher than the Z bar hangers on the wall. Lower the cabinet allowing the hangers to engage. Next with the cabinet resting on the hangers tap the bottom angle clips up and fasten with the provided screws.



800-434-4610
claridgeproducts.com

WARNING

Risk of injury to installers and users

Read the entire assembly directions before beginning assembly.