

## Markerboards

## INSTALLATION INSTRUCTIONS

## Tools Needed:

Laser/Level Drill/driver and drill bits Measuring tape Screwdriver Safety glasses Straight edge

## Instructions:

- 1. Mark desired height of the board on the wall.
- Measuring down from the desired height mark. Make a level line at 4", 25 1/2" and 47".
- 3. Place the bottom of the hanger on the lines and drill in the center of the
- 4. Attach the hanger with appropriate wall fasteners. Use a straight edge to check for flatness. Hangers may need to be shimmed accordingly.
- 5. Lift the board 2" above the desired height mark. While pressing the board to the wall, lower to engage the hangers.

**Note:** For boards taller than 5' measure down 21 ½" for each additional hanger.

WARNING

Risk of injury to installers and users

Read the entire assembly directions before beginning assembly.



claridgeproducts.com