



Grain Wood Trim Markerboards



INSTALLATION INSTRUCTIONS

WARNING

Risk of injury to installers and users

Read the entire assembly directions before beginning assembly.

Tools Needed:

Laser/Level
Drill and drill bit
Screwdriver
Tape measure
Rubber mallet
Safety glasses
Straight edge

Instructions:

1. Determined desired height of the top of the board and mark a line.
2. Lay the board face down and engage the Z bar hangers into the hangers mounted on the back of the board.
3. Measure from the top of the board to the bottom of the engaged z bar hanger. Transfer that measurement to the wall down from the desired height mark and strike a level line.
4. Place the bottom of the hanger on the level line and secure with proper wall fasteners.
Note: Make sure the wall hangers will align with the hangers on the back of the board.
5. Use a straight edge to check for flatness. Hangers may need to be shimmed accordingly.
6. From the desired height mark measure down the height of the board minus 1/2 "and mark a level line. Drill on the line to secure the angle clips. Clips should be plumb with the hangers. Use appropriate fasteners to mount the angle at its lowest point. Do not overtighten the clip to the wall. This will allow for the clip to be adjusted.
7. Install the board by raising the boards slightly higher than the Z bar hangers on the wall. Lower the board allowing the hangers to engage. Next with the board resting on the hangers tap the bottom angle clips up and fasten with the provided screws.



800-434-4610
claridgeproducts.com