



Glass Surface CARE & MAINTENANCE

- Dry Erase markers can be wiped off using a standard eraser, microfiber eraser cloth or any dry cloth. Permanent markers may be removed using a standard glass cleaner.
- Periodic cleaning may be performed using glass cleaner. Avoid using abrasive type cleaners as they may dull or “pit” the surface of the glass.
- Always use a soft cloth, towel or microfiber cloth from Claridge to clean your Claridge Glass writing surface.
- Avoid cleaning glass if the surface is hot or in direct sunlight.
- Avoid leaving tape or other adhesives on your glass writing surface for long periods of time.

Recommended Accessories:



Markerboard Cleaner

Product Code: LCS 683

- 8 oz. pump spray
- Cleans and restores LCS Porcelain enamel surface



Dry Erase Cloth

Product Code: ECM227E-each;

ECM227D-1 dozen

- 12" x 12" Microfiber eraser cloth with a small magnet
- Erases cleanly with no smearing
- Reduces marker residue build-up



Magnetic Eraser

Product Code: MGM-ME1

- Black felt eraser with strong rare earth magnets
- Measures 4-1/2" long, 2-1/8" wide and 7/8" thick



800.434.4610
claridgeproducts.com