



## Tack Surfaces CARE & MAINTENANCE

### **Claridge Cork**

- Wash with household soap or mild detergent to remove dirt and grime. Rinse, remove excess water, and allow board to dry.
- Stubborn stains and soil such as oil, lipstick, colored crayon, tape marks, etc. may be removed with cleaning fluid, alcohol, or WD-40. (Always follow proper safety procedures when using solvents.)
- Abrasive and/or alkaline cleaners should be avoided.

### **Tan Nucork**

- Soil may be removed by lightly sanding with very fine sandpaper or by erasing with art gum.

### **Fabricork**

- Washable, stain-resistant vinyl surface cleans easily with household soap, mild detergent or non-abrasive cleanser. Avoid harsh abrasives, as they may cause dulling of the vinyl surface.

### **Hook-Fab and Designer Fabric**

- Lint, dust and other particles that may adhere to the Hook-Fab surface or Designer Fabric surface may be removed with a garment brush/roller or with a “tacky” surface, such as the back side of cellophane tape.
- Dirty spots may be removed with a sponge and a mild household detergent such as Woolite.
- Grease stains or crayons should be first spot-cleaned with a lighter fluid containing naphtha to remove the solvent soluble matter. Any remaining stain can then be removed by shampooing, using a household upholstery cleaner.
- Do not over saturate Hook-Fab or Designer Fabric surface with too much water, detergent or upholstery cleaner. Doing so may cause damage to the backing under the fabric.

